



STEP 1
OPEN MASK



STEP 2
INSERT CHIN AND PULL HEAD
HARNES OVER HEAD WITH THUMBS



STEP 3
SMOOTH OUT EDGES OF MASK TO PROPER
FIT ON FACE. ADJUST HEAD HARNES
STRAPS IF NECESSARY



STEP 4
MASK IN PLACE
TAKE SEVERAL DEEP BREATHS IN ORDER TO
BECOME ACCUSTOMED TO THE MASK

CAUTION

1. MASK MUST BE PLACED IN CARRIER WHEN NOT IN USE.
2. MASK SHOULD BE HUNG, OR STORED IN A DRY, COOL, SHADED AREA.
3. AVOID CRUSHING THE MASK.
4. DO NOT REMOVE FIBERBOARD DEFLECTOR FROM MASK.

MASK, C B R, CIVILIAN

CD V-805

SIZE 3cB7

DT